



POS.	Tutti i tipi All types Alle Typen Tous les types Все типы	GS91100	GS91000**	GS90000*
1		RG000467	RG00467	RG00322
2	RG00323			
3		RG00468		
4	RG00325			
5	RG00326			
6	RG00327			
7		RG00439	RG00439	RG00439
8		RG00469		
3+8		RG00489	RG00489	RG00488
9	PSL0000			

*In produzione fino al 12/2005

*In production till 12/2005

*In Produktion bis 12/2005

*En production jusqu'en 12/2005

* В производстве до 12-2005 г.

**In produzione fino al 07/2007

**In production till 07/2007

**In Produktion bis 07/2007

**En production jusqu'en 07/2007

** В производстве до 07-2007 г.